



Notes:

Flashing steps/order: Prepare substrate per written specifications. Apply AP-42 or BP-40 per written specifications. Utilizing the UT-40, flash the bottom first over the flange carried across the substrate by minimum of 4". The sides are next, overlapping the bottom UT-40 application. The top will be flashed in last, overlapping the side(s) UT-40 application. Install FW-100A per written specifications.

BUILT IN WEEPS MUST NOT BE COVERED OR SEALED.

WINDOW FLANGE DETAIL

Wall Guardian FW-100A System, Not to Scale



830-995-5177

info@stscoatings.com

Manufactured by

Detail is intended to be a guide for air barrier installation only. As a manufacturer of construction materials, STS Coatings does not assume responsibility for errors in design or engineering. Architect or owners representative must verify suitability of details.



Rev: 122016