

MAKING REPAIRS TO DAMAGED MEMBRANE

Should the RGT membrane be damaged or punctured during application or due to installation of new roof equipment, etc., repairs should be made using either UT-40 Universal Tape **OR** RG-110 Flashing Compound with a non-coated polyester fabric as follows:

1. Damaged areas need to be cut, cleaned and dried.
2. If a new penetration area has been cut, apply UT-40 Universal Tape, minimum 6" wide, over damaged roof area, covering damaged area and extending at least 3" onto main secure roof membrane.

OR

 - (a.) Apply RG-110 Flashing Compound feathered out onto the existing RGT membrane and allow product to fully cure.
 - (b.) If a new penetration area has been cut, completely embed a non-coated polyester fabric into the RG-110 flashing compound according to RGT specifications, in a traditional 3-course method and allow product to fully cure.
3. Apply the appropriate RGT finish coat for a uniform color.

Special notes: For 15 and 20 year warrantied jobs, the UT-40 Universal Tape application must be utilized.